

WOODVIEW

Automotive Trim[®]



AVAILABLE FOR MOST:

CARS, TRUCKS, SUV'S, & VANS



PRODUCT FEATURES:

LIFETIME WARRANTY

100% PRECISION MOLDED COMPONENTS

"UV" RESISTANT, WILL NOT FADE

AUTOMOTIVE APPROVED MATERIALS

SUPERIOR QUALITY & DURABILITY

AIRBAG COMPLIANT



Installs easily over existing dash components. Provides a factory fit without ever removing the dash components from the vehicle.

STANDARD FINISHES:



ENGLISH BURLWOOD



BLACK CHERRYWOOD



AMERICAN WALNUT



STAINLESS BILLET



BRUSHED BRONZE



CARBON FIBER



INTERIOR TRIM PACKAGE

INSTALLATION INSTRUCTIONS

Tools Required: 1) Utility Knife 2) Paper Towels **Ideal Installation Temperature: 72F to 85F**
3) Cotton Swabs (5) 4) Hair Dryer
5) Rubber Gloves

Helpful Tips:

- 1) Dry fit all components in order to get a visual perspective on part placement before installing.
- 2) Install smallest components first in order to get familiar before attempting larger more difficult pieces.



LET'S GET STARTED:

Preparation & Cleaning



Using Isopropyl Alcohol, thoroughly clean all of the surface area that is to be covered by the dash components. The dash should be free of lint or contaminants before installing. Used or Pre-owned vehicles that have had Silicon Based vinyl treatments such as "Armor-All", or "Formula 2000" need to have special care. The adhesive will not stick to any surface that has any of this residue remaining. In these cases a stronger cleaner may be necessary. If the dash is dull in appearance, and you can feel no silicon residue on your fingers the dash should be fine. You can test the surface using a piece of masking tape to see if it adheres.

Applying the Adhesive Promoter



Open the packet of Adhesive Promoter enclosed with the dash kit in a dish. Using a Cotton Swab dip it into the Adhesive Promoter and carefully apply the product only to the surface areas that are to be covered by the trim pieces. **WARNING: Adhesive Promoter is highly corrosive and will permanently dis-color any part in the vehicle that it comes in contact with. We highly recommend the use of rubber gloves when applying the product to protect your skin. Please use only in a well ventilated area to avoid inhaling the fumes.**

An Adhesive Promoter Pen is available at an extra charge from the manufacturer. Each Pen lasts for 5-10 Dash Installations.

DETERMINE WHICH TYPE OF COMPONENT THAT YOU ARE INSTALLING AND CHOOSE "A" OR "B"

"A" Flat Component Application



Now you are ready to apply the Interior Package. First using your Utility Knife catch the corner of the Red Liner of the 3M Adhesive, and remove it. Be careful to try to avoid making contact with the adhesive surface in order not to contaminate the tape. Once the liner is removed carefully install the part "left to right" in order to avoid center buckling. Once the part is in place gently press down with your fingers to ensure that the product has made good contact. In bending situations, or in cold climate installations, use the Hair Dryer to soften the parts before bending. It will not only avoid breakage, but will make the tape more "tacky" for a better contact.

WARNING: The 3M 4229P Tape fully cures over a 72 hour period. Please avoid tampering with the Kit during this time. If you see a piece lifting, gently press it down into place.

"B" 3-D Molded Component Application



Using your Utility Knife, catch the corner of the Red Liner of the 3M Adhesive, and remove it. **See Fig. # 1.** Using the Dash Spray Pump Bottle included, gently mist the adhesive surface. This will make the tape temporarily less tacky to allow for easier installation.



See Fig # 2. Now you are ready to install the component. First gently tack the component in place without fully making contact. Once you are comfortable with your placement position, gently press the piece into place. Make sure that the component is not interfering with any control buttons, or switches. Make sure the component is fully bottomed out and is making good contact between the adhesive and the vehicle part.

Cleaning and Care

Clean your Dash Kit using water or Window Cleaner. Avoid using Vinyl Treatments that may effect adhesion over time.

WARRANTY COVERAGE

Woodview Automotive Trim products are warranted to be free of defective workmanship under normal use and service for as long as the original purchaser owns the vehicle. This warranty does not cover products that have been altered or handled improperly. Our obligation under this warranty shall be limited to repairing or replacing at our plant any defective parts. In the event that you would like to return your kit you must contact Woodview Corporation at 1-800-797-3274 and obtain a "Return Authorization Number". You must inspect all of the components in your kit before installing it to ensure that you are visually satisfied with the quality and fit of all of the components. **Warning:** Products installed on the vehicle, or that have the tape liner removed, will not be covered under the warranty.

THIS WARRANTY IS SUBJECT TO THE FOLLOWING LIMITATIONS

The obligation of Woodview is to repair any product that is considered defective to the original purchaser. The determination of a product defect is under the sole discretion of the product manufacturer. This warranty is limited to the manufacturer repairing or replacing any defective parts. Improper Installation is the sole responsibility of the installer of the product, and is not covered by warranty. The manufacturer will not be responsible for the warranty of any product that has been altered. All implied warranties shall be hereby excluded, including the warranties of merchantability and fitness for the intended purpose. The manufacturer will not be responsible for any defects or failures caused by accidental or unauthorized, unreasonable or negligent use of the vehicle or our products or parts. The manufacturer shall not be responsible for defects caused by the purchasers failure to comply with the installation instructions and/or care instructions.